



HDPE LOCKER CARE & MAINTENANCE

Summit PHDPE Lockers require periodic cleaning and semi-annual inspections/maintenance to maintain proper appearance and function.

Periodic Cleaning

- Clean Phenolic Lockers with a mild cleaning solution such as Formula 409, Windex or a simple soap and water mixture.
- For spot removal use a grease cutting product such as Simple Green or Goof Off.
- Do not use abrasive or acid based cleaning products.

Semi Annually Maintenance

- Check and tighten all locker screws, bolts and barrels, including but not limited to hinges, coat hooks, locker connection points, security screws, hasp, door pulls and locks.
- Repair phenolic scratches using SeamFil. SeamFil is available online.

Contact Summit Lockers if replacement parts are required.

Regards,

Mark Finkernagel
Summit Lockers Inc.